



Engine Connector

Pin #	Wire #	Function
1	K75	CANH
2	K53	CANL
3	A50	A50
4	K32	K32
5	K43	K43 / 5V
6	K61	K61 / Aps1
7	K62	K62 / GND
8	K18	K18
9	A60	A60
10	K31	K31
11	K86	K86
12	K87	K87
13	B63	B63
14	K88	K88
15	K35	K35





	B	R1	R2	ACC	C	BR
PRE-HEATING	○	○	○	○	○	○
OFF	○	○	○	○	○	○
ON	○	○	○	○	○	○
START	○	○	○	○	○	○

Connection to Dash



Turn Signal and Light Switch

Lights	Black/Yellow			Gray			Orange			Red			Yellow			Brown		
	Headlight	Interior	Turn	Headlight	Interior	Turn	Headlight	Interior	Turn	Headlight	Interior	Turn	Headlight	Interior	Turn	Headlight	Interior	Turn
Turn			Left			Right												



Model: RS35

Electric Schematic V3

© 2025 Third Coast Equipment Inc. Unauthorized reproduction prohibited. All rights reserved. Download the latest at: WWW.THIRDCOASTEQUIPMENT.COM